



User Manual




Thank you for choosing us. Please read this user manual before using the speaker.



User Manual

Thank you for choosing us. Please read this user manual before using the speaker.

Operation Image:



Material	ABS + Metal
Lamp Power	1.6W
Lumen	160LM
Color Temperature	Warm white
LED Size	2835
Battery Li-ion	3.7V, 1,800 mAh
Speaker output power	3W
Driver Unit	φ 52mm, 4Ohm, 3w
Frequency Response	50HZ--20KHZ
Transmission Range	10 meter
Product dimension	φ 95mm * 122mm
Audio input	3.5mm jack cable
frequency	2.402GHZ--2.48GHZ
Input power	Input DC5V/500mA

Playing time after fully charged:

10 hours music playing for normal 70% volume, 10 hours lighting lamp on highest brightness

Power switch:

Long press to turn it on or off. The speaker will first enter Bluetooth Mode ; Press Mode switch to turn Lighting Mode when the speaker is on, light will be on by soft touch .Bluetooth Mode will instantly switch when click the Mode button icon (TF Card Music Playing will automatically switch when inserted TF card).Voice Prompts will sound before bluetooth pairing and TF card music playing

Button icon:

1, Mode icon:

achieve bluetooth mode and TF card music playing , lighting mode changing freely

2, Bluetooth music mode:

Short press to play the next song and long press to volume up.

Short press to play the previous song and long press to volume down.

3, Hands free calling:

Answer and hang up the phone:

There will be an alert sound from the speaker when there is a phone call. Click

to answer the call, and click again to hang up .

4, TF card music playing:

Enter TF card music playing mode automatically when TF card inserted

Short press to play the next song and long press to volume up.

Short press to play the previous song and long press to volume down.

Music playing or pause by click

Bluetooth mode will switch by click the MODE button when on TF card music playing mode

5, AUX IN audio input mode:

Inserting the 3.5 mm aux in cable, the speaker can be an external audio when connected with mobile phone, PC, tablet, mp3.

In Aux in audio input mode, to volume up, to volume down, other buttons are out of use. In any mode, when inserted 3.5 mm audio in cable, the speaker self identified and automatically switch to audio in input mode.

Indicator light:


1, Bluetooth indicator:



LED多功能藍芽音箱燈 使用說明



操作說明



技術參數

輸出功率: 3W
內置鋰電池電壓: 3.7V
標準規範: V2.1+ EDR
藍芽頻率: 2.4GHZ~2.48GHZ
傳輸距離: 10M
頻響範圍: 50Hz~20KHz
整機信噪比: > 75db
產品尺寸: φ95mm x 122mm
充滿電後, 正常音量(70%)可持續播放10小時左右, 燈燈最高亮度可使用10小時左右。

充電輸入: DC 5V / 500 mA
藍芽協議: A2DP 1.2

開 / 關機

長按 鍵, 開機後音響首先進入藍芽模式, 按MODE模式鍵, 可切換到燈燈模式, 輕觸喇叭網可開啟燈燈。(若插入記憶卡, 則會自動進入記憶卡音樂播放模式); 藍芽模式及記憶卡音樂播放模式均有語音提示, 可進行藍芽配對或記憶卡音樂播放。

按鍵操作

1. MODE模式鍵, 可輕鬆在藍芽模式與記憶卡音樂播放模式之間切換。

2. 藍芽無線音樂撥放模式

輕按為上一首, 長按音量將持續減小。

輕按為下一首, 長按音量將持續增加。

撥放音樂時輕按可暫停 / 撥放音樂; 來電時輕按為接聽與掛斷通話功能。

3. 記憶卡音樂撥放模式

插入記憶卡後自動進入記憶卡音樂撥放模式

輕按為上一首, 長按音量將持續減小。

輕按為下一首, 長按音量將持續增加。

撥放音樂時輕按可暫停 / 撥放音樂。

在記憶卡音樂撥放模式下, 按“MODE”鍵可切換為藍芽模式。

4. AUX音源輸入模式

插入3.5mm音源線, 連接手機、電腦、平板電腦、MP3等, 可作為外接音響使用。

在AUX模式下, 可按 增加音量, 或按 減小音量, 其他按鍵均無效。

在任何模式下只要插入3.5mm音源線, 系統會自動識別, 並切換為AUX音源輸入模式。

The Bluetooth indicate light will flash rapidly when in impairing state,the blue light flash slowly means bluetooth connected, the speaker enter bluetooth music playing.

2,TF card music playing indicator:

The speaker enter TF card music playing when blue indicate light flash in TF card playing mode

3,Charging:

1,Please make sure the speaker is fully charged in first use. Charge the speaker with the provided USB cable which is compatible with any computer or cell phone 5 V output charger. The charge indicator light will be red while charging, then when the battery is fully charged it will turn off.

2,Charge time :about 4 hours

Bluetooth mode:

1,Bluetooth connection:

This speaker supports the bluetooth device with A2DP function.Slide the power switch first,then enter bluetooth mode,bluetooth indicate blue flicker alternately,together with voice prompts,the speaker is in impairing state at this moment,and only in the state bluetooth can be impaired and connected successfully.

2,Mobile phone connection:

Step 1: Open the Bluetooth setting on your phone or tablet and click "search device". Iphone will search for Bluetooth devices automatically.

Step 2: You have found the Bluetooth speaker when the screen displays the character "LV2016",click on it in your device to pair the connection.

Step 3: Enter"0000" and click OK if there's a prompt that requires you to enter a password.

Step 4: The phone or tablet will indicate when the pairing is successful. The character on the display of the speaker will stop flickering.

3,Computer connection:

Activate the bluetooth function first if the computer has bluetooth device.It's necessary to install the bluetooth driver and plug in the bluetooth adapter when there is no bluetooth available

Step 1:Click the bluetooth icon at the lower right the computer by mouse right button,choose"device adding"

Step 2:Bluetooth adapter will search for the speaker automatically,and the screen displays the character "LV2016".

Step 3:The computer will install the driver automatically after double click the the character "LV2016",and display driver install successfully.

Step 4:Double click the bluetooth icon,the speaker connects the computer successfully and be in use.Please check the computer audio device has switched to bluetooth mode or connected well if the speakerstill can not play music successfully.

Bluetooth pairing and connection

1. If the speak has been connected with Bluetooth devices before, it will connect with the last Bluetooth device

automatically once it is turned on.

2.If the speak has not been connected with Bluetooth devices before,it will enter impairing mode,click connecting is achievable

3.Other phones or tablets can not be connected with the Bluetooth speaker when the speaker is being connected with a phone or tablet.

4.The phone or tablet can not be connected with the Bluetooth speaker if it is connected with other Bluetooth devices. You should turn off your Bluetooth connection and connect your phone with the Bluetooth speaker again.

Lamp function

Long Press the switch of the speaker on the bottom. Turn on the light by tap the mesh on the top, and the lamp will light on in the dimmest grade one. The brightness can be adjusted by tap the top mesh, and there are 3 brightness grades: low brightness , intermediate brightness, and high brightness. Tapping the top mesh when in high brightness, the light will be off.

Frequently Asked Questions

Questions	Solutions
Unsuccessful pairing and connection repeatedly	1.Check the speaker and make sure it is in the searching state or reboot the speaker. 2. Connection is difficult when there are too many Bluetooth devices nearby. Turn off other Bluetooth devices. 3.Turn off the Bluetooth device that was connected with the Bluetooth speaker last time, and reconnect the speaker .
Muted or distorted sound	1.Check the volume of your phone or the speaker, and adjust the volume. 2.The battery is low. Please charge it.
Choppy music play	1. Check if the device is beyond the effective connection distance. 2. Check if there is any obstacle between the speaker and your device.
The indicator not shining in Bluetooth mode	1.The battery is low. Please charge it. 2.Please reboot the speaker.

指示燈說明

1.藍牙指示燈

藍牙指示燈藍燈閃亮表示進入藍牙配對狀態，藍燈慢閃表示已經連接上藍牙設備，音響進入藍牙播放模式。

2.記憶卡撥放指示燈

指示燈藍燈閃爍，表示音響進入記憶卡音樂撥放模式。

3.充電指示燈

充電指示燈紅燈亮表示正在充電，充滿電後紅色指示燈熄滅。

如何充電

1.可通過USB線連接電腦與音響，音響在開關機狀態下都可以充電。

2.可以連接符合USB規格，5V輸出的電源供應器充電，充電時紅色指示燈亮，充電時間約4小時，電池充滿後，紅色指示燈熄滅。

藍芽功能使用

1.藍芽連接

本音響支援具有A2DP功能的藍芽設備使用。首先長按開/關機鍵開機，進入藍芽模式，藍芽指示燈的藍燈閃亮，並伴有語音提示，此時音響處於等待配對連接狀態，而且只有在這個狀態下，才能與藍芽音響進行配對與連接。

2.手機連接

第一步、在手機設定中，打開手機藍芽設定開關，點擊掃描查找設備
第二步、當可用設備顯示“LV2016”字樣，表示手機已找到藍芽音響，點擊“LV2016”進入配對模式。
第三步、如配對過程中，出現需要輸入密碼的提示，請輸入“0000”即可。
第四步、手機與音響配對成功後，會有語音提示，並顯示以連接。

3.電腦連接

如果電腦具有藍芽功能，先開啟藍芽功能。如果電腦沒有藍芽功能，就必須先安裝藍芽驅動，並插上藍芽接收器，才能使用藍芽功能。

第一步、用滑鼠右鍵點擊電腦桌面右下角藍芽符號，選擇“添加設備”

第二步、藍芽接收器將自動搜索音響，並會顯示“LV2016”。

第三步、雙擊“LV2016”後，電腦將自動安裝驅動，並顯示安裝驅動成功。

第四步、點擊連接，音響與電腦連接上就可以使用了；如果還不能用音響來播放，請檢察電腦的聲音輸出設備是不是已經切換到藍芽模式，並確認電腦是否與電腦連接上了。

配對與連接

1.如果音響上次與其他藍芽設備有連接過，開機後將主動連接上次連接過的設備。

2.如果音響之前未與手機或其他設備連接過，音響進入配對模式，點擊配對連接即可。

3.本設備與一部手機或設備正在連接狀態時，其他手機無法連接到本設備。

4.當手機與其他設備連接時，無法與本設備進行藍芽連接，一定要先關閉其他設備連接，然後重新啟動藍芽音響，進入配對模式，重新配對連接即可。

燈燈使用

暖光模式：開機，任何模式下輕按金屬網開啟，再次按下可調亮，亮度共分三段。

七彩燈模式：(長按金屬網切換為七彩燈模式)在彩燈模式下短按：紅、藍、綠、紫、淡藍、呼吸燈(顏色隨音樂節奏跳動)，再按一次為關燈。

常見問題	解決方式
多次連接配對不成功	1.檢查音箱是否處於搜索狀態，或重新開機。 2.周邊藍芽設備太多，造成搜索困難，關閉其他藍芽設備。 3.斷開上次與音箱連接的藍芽設備，進行新的連結。
聲音過小或失真	1.檢查手機或設備音量值，調整音量。 2.電池電壓低，請充電。
音樂撥放出現斷音	是否超出音箱有效連接距離，或音箱與設備間有障礙物。
藍芽狀態指示燈不亮	1.電池電量 2.重新開機，電量不足，請充電。